



Blending Table Assembly Instructions




Fig 1: Carriage Bolt & Kep Nut Assembly

Drawer Stop Installation:

1. Pinch the flared ends of the drawer stop and insert this end into the large rectangular hole nearest the front of the table.
2. Rotate the flared ends into the smaller rectangular hole and release them.
3. The drawer stop needs to be installed into the holes nearest the front of the table on both sides.
4. It is easier to install the drawer stops without the drawer in place. Once the stops are installed into the hangers the drawer should slide into place and then not slide all the way out.




Fig. 2: Drawer Components




Fig. 3: Viewer Assembly

For the 94cm (37in) Large Blending Table:

Caution: Safety steel gloves must be worn when handling steel because galvanized edges may be sharp.

- 1) Place the plastic feet on each of the legs.
- 2) Attach the legs to the top shelf using the 0.6 cm x 1.5 cm carriage bolts (Ref. 7) and kep nuts (Ref. 8). (Fig. 1)
- 3) Slide the bottom shelf into the lances on the legs, and tighten all bolts

Note: Be sure that the legs are on the inside of the top shelf.

If the table is equipped with a:

- **Stainless Steel Top** - Place the stainless steel work top over the top shelf.

- **Drawer** - (Fig. 2) Slide the drawer onto the hangers (Ref. 12).

Note: The drawer stops (Ref. 13) must be located toward the front of the table underneath the top shelf in order for the drawer to function properly.

- **Viewer column and hardware** - (Fig. 3) Viewer column can be attached to either side of the table using the two U-bolts (Ref. 2) and four wing nuts (Ref. 3). Position the viewer column to the desired height and lock into position.

Note: Be sure that the wing nuts are tight.

- **Viewer Shelf** - Slide the tube on the viewer shelf over the column.

Note: Some Blending Tables are not supplied with the stainless steel top, column, drawer, or viewer shelf.

For the 53cm (21in) Mini Blending Table:

Caution: Safety steel gloves must be worn when handling steel because galvanized edges may be sharp.

Assembly:

- 1) Place the plastic feet on each of the legs.
- 2) Attach the legs to the top shelf using the 0.6 cm x 1.5 cm carriage bolts (Ref. 7) and kep nuts (Ref. 8). (Fig. 1)
- 3) Slide the bottom shelf into the lances on the legs, and tighten all bolts

Note: Be sure that the legs are on the inside of the top shelf.

If the table is equipped with a:

- **Stainless Steel Top** - Place the stainless steel work top over the top shelf.

- **Viewer column and hardware** - (Fig. 3) Viewer column can be attached to either side of the table using the two U-bolts (Ref. 2) and four wing nuts (Ref. 3). Position the viewer column to the desired height and lock into position.

Note: Be sure that the wing nuts are tight.

- **Viewer Shelf** - Slide the tube on the viewer shelf over the column.

Note: Mini Blending Tables are not supplied with a drawer and some do not have the viewer shelf.